

GRAFFITI REMOVER

Description

Graffiti Remover is a high quality, user-friendly gel for universal use on non-permeable substrates. Removes spray can paint, felt tip markings, latex paint, lipstick, etc. from doors, traffic signs, shutters, transformer housings, underground train stations, railway rolling stock, etc. Safely and thoroughly removes graffiti from painted, varnished or coated materials, Trespa, Plexiglas, Lexan, etc. without degrading the material.

Always try a test piece first!

Properties

- Easy to use
- Very effective
- Gel structure

Application

Spray Graffiti Remover on the surface or fabric that requires treatment. Use a soft cloth or sponge to rub the product in well. After the graffiti has dissolved, wipe it off and clean the area with clean water and detergent to prevent staining. Graffiti Remover is neutralised immediately when it comes into contact with water and detergent.

Always try a test piece first!

TECHNICAL DATA

Content: 500 ml

VOC content: Approximately 92 m/m %

Solid components: Approximately 8 m/m %

Hazard classification: See MSDS

Storage: Minimum of 12 months in the tightly sealed original packaging in a dry, cool and frost-free place.

General: Do not use at temperatures below 10°C. Do not use outside when it is likely to rain, frost is expected, or in direct sunlight. The spray can must be kept at room temperature (minimum of 15°C). Never place the spray can on a heat source.

Surplus product: This paint and the packaging should be disposed of at a collection point for hazardous or special waste.