

**Description:** Decorative, matt, latex wall paint based on synthetic resin dispersion and with good hiding power. For interior use.

**Application:** For interior walls and ceilings when a colour finish is required. Less suitable for rooms that become damp and moist such as kitchens and bathrooms. Suitable substrates are: Cement and plasterwork, concrete, brick, plasterboard, board, wallpaper etc.

**Properties:**

- Good hiding capacity
- Lightly washable
- Easy to apply

**Colours:** Various colours

**Handling:** Stir thoroughly prior to use. Dilute the first coat with no more than 10% of water if required. Apply the second coat undiluted. Apply 1 or 2 coats using a woolly roller, particularly if applying on rough surfaces. Use a brush for corners etc.

**Covers:** According to ISO-6504-3 and DIN EN13300 approx. 7m<sup>2</sup>/litre per coat, depending on the surface. Deposition efficiency: class 3

**Drying time at 23°C and relative humidity of 65%:**  
Dust-dry after approx. 2 hours.  
Can be painted over after approx. 6 hours.

**SYSTEM CONSTRUCTION**

**Substrate:** The surface must be clean, dry and free from dust or grease. Sand and repair surface irregularities. Remove and/or repair all loose and unstable coats.

**New plasterwork:** Prime with Finess Wall Paint Primer or Finess Transparent .

**Existing plasterwork:** Clean using water and a degreasing agent. Allow to dry. Prime with Finess Wall paint Primer.

**Powdery substrates:** Clean thoroughly with clean water and allow to dry. Prime with Finess Stabilising Primer.

**Non water-resistant (rub-resistant) coats of paint:** Wash thoroughly until the surface does not flake or dust anymore. Next, prime with Finess Stabilising Primer.

**Concrete:** Remove any 'cement skin' and dust thoroughly using a brush. Next prime the surface with Finess Wall Paint Primer.

**Aerated (cellular) concrete blocks:** Prime using a special priming agent. Next, apply a coat of plaster. After drying, prime the surface with Finess Wall Paint Primer.

**Plasterboard:** Bridge the joints with plaster mesh tape and fill with a suitable filler. After allowing to dry: Next prime the surface with Finess Wall Paint Primer..

**MDF, chipboard and fibreboard:** Sand smooth boards, remove any dust and seal the surface using Finess Sealing Primer.

**Load-bearing coats of paint:** Clean using water and a degreasing agent. First, sand down glossy coats of paint until matt and carefully ensure the substrate is free of dust.

**Substrates stained by nicotine, damp, rust or soot:** Wash with water and a degreasing agent and allow to dry well. Next, seal the surface of the substrate with Finess Sealing Primer.

**TECHNICAL DATA**

**Binding agent:** Vinyl copolymer dispersion

**Pigments:** Rutile titanium dioxide, fine extenders and pigments

**Solvent:** Water

**Solid components:** 63% by weight

**SG:** Approx. 1.6 g/ml

**Viscosity:** Viscolab LC 3: 5 PaS @ 20°C

**Fineness:** 50 microns

**Degree of gloss:** Matt ISO-2813 and DIN EN 13300: 60°/2,5% 85°/20%

**Tint:** Various colours

**Dilute with:** Water

**Hazard classification:** See safety information sheet (MSDS)

**Tool cleaning instructions:** Water

**Features:** Washability according to DIN 53778: 250 cycles. Scrubability according to ISO-11998 and DIN EN 13300: class 4

**Storage:** Minimum of 12 months in the tightly sealed original packaging in a dry, cool and frost-free place.

**General:** Do not use at temperatures below +8°C. Allow newly cemented surfaces to set for at least 6 weeks.

**Surplus product:** This paint and the packaging should be disposed of at a collection point for hazardous or special waste.